## **ROOF TOP STICK MINERAL**

Self-adhesive top layer

WATER

1911<sup>°</sup>





#### Product description

A high-quality self-adhesive roofing membrane for gently pitched roofs with a minimum slope of 2° that ensures a waterproof roof. Its self-adhesive nature eliminates the need for adhesive or torching. Making this the simplest and safest way to install a roof covering. The top layer has a peel-off film, for quick and easy installation. Made from high-quality elastomers and bitumen with a polyester-glass combination insert so the roll tear- and shrink-resistant. The unique composition of the bitumen makes this top layer strong, elastic and easy to work with. The top layer is finished with light grey slate granules for additional UV protection.

### Application

For use as a top layer in a 2-ply system on flat roofs with a gentle pitch of minimum 2°. Suitable for both new build and the refurbishment of existing roofs. When used in refurbishment, the existing roof covering can be used as the underlay providing it is still in good condition. Roof Top Stick Mineral can also be used in a single-ply system if the roof pitch greater than 8°.

#### Advantages

- Quick and easy to apply
- Safe installation
- Resistant to extreme weather conditions

### Storage and use

- The ideal application temperature is between 5°C and 25°C. It cannot be applied in freezing temperatures.
- Allow the self-adhesive roofing membranes to warm up indoors for 12 hours prior to installation.
- For a roof pitch greater than 8°, a single-ply system with the ROOF TOP STICK is sufficient. Always work from bottom to top on a pitched roof.





# **ROOF TOP STICK MINERAL**

Self-adhesive top layer













#### How do I prepare the surface?

- First remove all dust and grease from the substrate.
- In the case of renovation, repair any blisters, cracks and tears in the weathered bitumen substrate with elastic ROOF REPAIR REGULAR. Reinforce with ANTI-CRACK, a tear-resistant polyester fleece. In the case of new construction, use ROOF BASE STICK as an underlay.

### How do I use the product?

- Place the **ROOF TOP STICK** on the roof surface. Always start at the lowest point of the roof, i.e. the side with the rainwater outlet. Lay the **ROOF TOP STICK** in the same direction as the underlay or the existing roof covering used as an underlay, but staggered by 50 cm. To achieve this, halve the width of the first roll of roofing membrane.
- Unroll it to check the alignment. Then roll the ROOF TOP STICK back up halfway. Apply ROOF PRIMER STICK ACTIVATOR to the substrate where the roofing mebrane will be installed to ensure good adhesion. Wait until it is dry to the touch (5 to 10 minutes).
- Carefully cut through the film without damaging the roll. Remove the peel-off film from the **ROOF TOP STICK** and firmly press the underlay onto the substrate. Press from the inside to the outside so that no air is trapped during unrolling. Press the seams well with a seam roller.
- Repeat with the other half of the roll.
- When installing the next roll of **ROOF TOP STICK**, ensure an 8 cm overlap lengthwise. Cut the roll to size, roll it back up halfway, remove the peel-off film from the seams, remove the peel-off film from the roll and stick it using the same method as above.
- Ensure a 15 cm overlap in the width (the end seams between the rolls). Make sure the end seams are staggered relative to the underlying and adjacent rolls.
- Finish the upstands with strips of **ROOF TOP STICK**. First apply **ROOF PRIMER STICK ACTIVATOR** to the upstands to ensure optimum adhesion. Wait until the **ROOF PRIMER STICK ACTIVATOR** is dry to the touch (5 to 10 minutes). Then apply the strips of **ROOF TOP STICK**. Ensure that the strips extend at least 10 cm onto the roof surface. Cover all the upstands with strips.

## Would you like more information?

We are ready to answer all your questions. Feel free to contact us: Belgium: 03 248 30 00 or info@aquaplan.com The Netherlands: 0162 42 29 00 or verkoop-dhz@martensgroep.eu Website: www.aquaplan.com

