

BATHROOM PROTECT

Waterproof coating for bathrooms and kitchens



PRODUCT DATA SHEET



Product description

A waterproof coating that makes all horizontal and vertical surfaces, even damp ones, in bathrooms and kitchens 100% waterproof before finishing them with tiles, among other things. **BATHROOM PROTECT** is ideal in combination with **ASCOFIX STICK & FIX**, a universal and elastic tile adhesive. It can also be used on difficult substrates.

Application

For use on all substrates (even when damp) such as wood, plasterboard, aerated and cellular concrete, plaster, sand-cement screed, masonry, etc.

Advantages

- › Elastic
- › Can be used on all types of substrates
- › Suitable for walls and floors
- › Environmentally friendly and safe to use
- › Easy to apply

How much product do I need?

One litre of Bathroom Protect treats:

- 3 m² surface area
- Or 8 running metres corner

See also the calculator on our website www.aquaplan.com.

Handy tips?

- Store in a cool (max. 20°C) and frost-free place
- Only suitable for application indoors.
- Not suitable for sealing "basins" that permanently hold water.
- Clean your equipment with water immediately after application.

Material	Colour	Contents	Coverage	Drying time	Coats	Overpaintable
Resin	White	0,70 L / 2 L	3 m ² /L	About 12 hours	2	Yes

BATHROOM PROTECT

Waterproof coating for bathrooms and kitchens



INSTRUCTIONS



What do I need?



How do I prepare the surface?

- First remove all dust and grease from the substrate.
- Seal any cracks and tears and fill holes with **BASEMENT PROTECT REGULAR PLUG**.
- If the substrate is too rough, level it before tiling.
- Use of a special adhesive coat is **NOT NECESSARY** and the substrate can be slightly damp.



How do I use the product?

- **BATHROOM PROTECT** before use.
- Apply a first coat of **BATHROOM PROTECT** with a brush or roller, using approx. 0.15 l/m².
- After 2 to 3 hours (at 20°C), reinforce all wall and floor joints with **ANTI-CRACK**. Always reinforce the horizontal corners first and then the vertical ones. See the **ANTI-CRACK** packaging for detailed application instructions.
- Apply a second coat of **BATHROOM PROTECT** immediately after reinforcing all corners.
- Apply an extra coat around pipes and drains.
- Allow to dry for about 12 hours (at 20°C) before using or tiling the room.
- Ventilate the room well to speed up the drying process.



Usage	Drying time	Cleaning
2L ± 5,5 m ²	12 hrs	H ₂ O

Would you like more information?

We are ready to answer all your questions.

Feel free to contact us:

Belgium: 03 248 30 00 or info@aquaplan.com

The Netherlands: 0162 42 29 00 or verkoop-dhz@martensgroep.eu

Website: www.aquaplan.com

