

FOUNDATION PROTECT REGULAR

Waterproof protection for all buried materials



PRODUCT DATA SHEET



Product description

Universal coating based on bitumen, solvents and adhesives for waterproofing along the outside of all buried materials made of stone, concrete, wood and metal (foundations, walls, socles, posts, etc.) that come into contact with soil. After curing, it forms a tough, elastic, seamless, moisture-resistant coating that seals all pores and microcracks. The treated surface is effectively protected against the aggressive influences of groundwater (humus, saline solutions, dilute organic acids and alkalis). Can be applied in both summer and winter.

Application

For use on all types of buried surfaces consisting of stone, concrete, wood and metal such as slabs (e.g. garden sheds, etc.), convector shafts, septic tanks, reservoirs, sewage pipes, garden posts, cisterns, drainpipes, etc.

Advantages

- › Dries quickly, quickly waterproof
- › Adheres to any substrate
- › Can be applied in winter and summer
- › Seals all pores and micro-cracks

How much product do I need?

Use about 0.3 litre per m² for each coat.

On cement 2 coats are sufficient, apply 3 coats to masonry.

See also the calculator on our website www.aquaplan.com.

Handy tips?

- Store in hermetically-sealed packaging, away from any heat source.
- Stir well before use.
- Clean your tools with white spirit or turpentine.

Material	Colour	Contents	Coverage	Drying time	Coats	Overpaintable
Bitumen emulsion	Black	4 L / 20 L	Approx. 3 m ² /L	About 24 hours	2 - 3	No

FOUNDATION PROTECT REGULAR

Waterproof protection for all buried materials



INSTRUCTIONS



What do I need?



How do I prepare the surface?

- Ensure the surface is sound and free of loose particles.
- First remove all dust and grease from the substrate.



How do I use the product?

- Stir **FOUNDATION PROTECT REGULAR** well before use.
- Apply at least 2 undiluted cross coats of **FOUNDATION PROTECT REGULAR** with a brush or roller at a rate of 0.3 l/m² per coat. A third coat is recommended for masonry. Make sure each coat is protected from rain for at least 4 hours.
- Only apply the next coat after the previous coat has fully cured. This takes about 24 hours.



Would you like more information?

We are ready to answer all your questions.

Feel free to contact us:

Belgium: 03 248 30 00 or info@aquaplan.com

The Netherlands: 0162 42 29 00 or verkoop-dhz@martensgroep.eu

Website: www.aquaplan.com

