# FLEXIFOIL DETAILS & SEAMS

Glue for sealing EPDM seams and details.









### Product description

A high-quality, solvent-free adhesive glue for bonding FlexiFoil EPDM membrane and waterproofing seams, accessories and profiles. Thanks to its unique technology, this glue is highly elastic, highly adhesive and waterproof. This adhesive glue can be used both horizontally and vertically.

### Application

For bonding FlexiFoil EPDM membrane to FlexiFoil EPDM membrane, wood, concrete, stone, lead, bitumen roofing rolls or PIR insulation panels with glass fleece.

#### Advantages

- Highly adhesive
- Very elastic and waterproof
- Solvent-free and odourless

#### How much product do I need?

A 290 ml tube is enough for

- About 1.5 running metres of gutter
- About 7 running metres of roof and wall profiles
- Bonding two accessories

### Handy tips?

- FlexiFoil Details & Seams is compatible with Roof Glue EPDM Overlap.
- With FlexiFoil Details & Seams, you can also bond an EPDM membrane using beads of glue.
- The drying time depends on the temperature, amount of wind and humidity.
- Make sure some product always emerges from under the membrane to ensure waterproofing. If you want a nice finish, you can smooth out the excess product using a small spoon or the back of an empty tube.
- Use FlexiFoil Details & Seams for repairs. Always use a rounded piece of EPDM membrane to cover a crack or small hole in an existing EPDM membrane, and use FlexiFoil Details & Seams for the adhesion of both membranes.
- Store in a frost-free place.
- Do not apply if the ambient or substrate temperature is below +5°C.

Material	Colour	Contents	Coverage	Drying time	Coats	Overpaintable
Glue	Black	290 ml	1 tube is enough for approx. 1.5 running metres of gutter or approx. 7 running metres of roof and wall profiles	/	1	No

## FLEXIFOIL DETAILS & SEAMS

Glue for sealing EPDM seams and details









### What do I need?



### How do I prepare the surface?

• First remove all dust and grease from the substrate.

### How do I use the product?

- Apply FlexiFoil Details & Seams using a caulking gun.
- Seams: Apply **FlexiFoil Details & Seams** 2 cm from the edge of the seam. Accessories: Trace the outline of the accessory. Depending on the accessory, apply **FlexiFoil Details & Seams** 2 cm inside the drawn outline, around the drain and 2 cm on both sides of the corners (for preformed corners). Place the accessory on the glue.
- Use a roller to seal the seam well. The product under the seam should emerge. Remove any excess product.
- Bonding of FlexiFoil EPDM membrane: For small areas, you can apply this glue in beads (every 50 cm) using a caulking gun. Press down firmly with a roller.



### Would you like more information?

We are ready to answer all your questions. Feel free to contact us: Belgium: 03 248 30 00 or <u>info@aquaplan.com</u> The Netherlands: 0162 42 29 00 or verkoop-dhz@martensgroep.eu Website: <u>www.aquaplan.com</u>



JAPLAN

protects your home.