

ROOF PRIMER STICK ACTIVATOR

Ready-to-use pre-treatment agent for self-adhesive bitumen roofing membranes



PRODUCT DATA SHEET



Product description

A black, ready-to-use pre-treatment agent to promote adhesion of self-adhesive bitumen roofing rolls. The use of **ROOF PRIMER STICK ACTIVATOR** activates the adhesive power of self-adhesive bitumen roofing membrane, resulting in excellent adhesion even in non-ideal conditions. **ROOF PRIMER STICK ACTIVATOR** is easy to apply. Remove the peel-off film from the self-adhesive bitumen roofing roll and place it on the treated surface.

Application

For use on concrete, wood, older bitumen roofing membranes, PIR insulation panels with glass fleece and self-adhesive bitumen underlays before applying the self-adhesive vapour barriers or rolls of roofing.

Advantages

- ▶ Easy to apply
- ▶ Dries very quickly (5 to 10 minutes)
- ▶ Adheres to all substrates

How much product do I need?

Use approx. 1 litre per 5 m² per coat.

See also the calculator on our website www.aquaplan.com.

Handy tips?

- Close the container. Store dry in a cool (max. 20°C) well-ventilated area.
- The application and product temperature must be between +5°C and +30°C.
- Use **ROOF PRIMER STICK ACTIVATOR** on upstands and around small roof details. For larger, horizontal surfaces, we recommend **ROOF PRIMER STICK ACTIVATOR 5 l**.
- The product can be manually agitated before use.
- Only for use with self-adhesive bitumen roofing rolls. Do not use with bitumen roofing rolls that must be heat welded or bonded with bitumen cold glue.

| Material | Colour | Contents | Coverage | Drying time | Coats | Overpaintable |
|----------|--------|--------------|---------------------------|-----------------|-------|---------------|
| Coating | Black | 750 ml / 5 l | About 5 m ² /l | About 5-10 min. | 1 | No |

ROOF PRIMER STICK ACTIVATOR

Ready-to-use pre-treatment agent for self-adhesive bitumen roofing membranes



INSTRUCTIONS



What do I need?



How do I prepare the surface?

- Remove all dust and grease from the substrate.
- The product can be manually agitated before use.

How do I use the product?

- Apply 1 thin coat of primer to the substrate with a spray or roller. Distribute the primer evenly.
- Wait 5 to 10 minutes (at 10°) so the solvents can evaporate.
- Apply an Aquaplan self-adhesive roofing roll on the prepared substrate. Do not forget to remove the peel-off film from the roofing roll and press firmly.

| Usage | Drying time | Tools |
|---------------------------|-------------|-------|
| 1 L ± 5 m ² | 5-10 min | |

Would you like more information?

We are ready to answer all your questions.

Feel free to contact us:

Belgium: 03 248 30 00 or info@aquaplan.com

The Netherlands: 0162 42 29 00 or verkoop-dhz@martensgroep.eu

Website: www.aquaplan.com

