

# ROOF PRIMER ROOFING

Bitumen bonding varnish for roofs



PRODUCT DATA SHEET



## Product description

A bituminous and quick-drying bonding varnish to prepare the substrate for the installation of bitumen roofing membranes or the application of roof coatings. **ROOF PRIMER ROOFING** fixes residual dust and loose particles, ensuring optimum adhesion to new bitumen roofing membranes or renovation coatings on dry and slightly damp substrates. This primer penetrates deep into the substrate and dries very quickly. It's also used to pre-treat aluminium rainwater drains before finishing the roof.

## Application

For use on bitumen roofing before gluing or heat welding new rolls of roofing or applying bituminous renovation coatings. It is also suitable for other surfaces such as concrete, metal, fibre cement, etc.

## Advantages

- › For all substrates
- › Dries quickly
- › Ensures optimum adhesion
- › Easy to apply

## How much product do I need?

About 0.2 l/m<sup>2</sup>

## Handy tips?

- **ROOF PRIMER ROOFING** is made from bitumen and quick-drying solvents.
- Store in a cool, dry place.
- Do not apply if the ambient temperature is below +5°C or above +35°C.
- The amount of product required depends on the substrate: for metal approx. 10-14 m<sup>2</sup> per litre; for concrete approx. 4 m<sup>2</sup> per litre; for bitumen roofing approx. 5 m<sup>2</sup> per litre, for fibre cement approx. 12 m<sup>2</sup> per litre.
- Clean your tools with white spirit or turpentine.

Material	Colour	Contents	Coverage	Drying time	Coats	Overpaintable
Bitumen and solvents	Black	1 L / 4 L	About 5 m <sup>2</sup> /l	About 3 hours	1	Yes

# ROOF PRIMER ROOFING

Bitumen bonding varnish for roofs



INSTRUCTIONS

## What do I need?



## How do I prepare the surface?

- First remove all dust and grease from the substrate.
- Degrease with acetone if the primer is used on metal.



## How do I use the product?

- Apply a layer of **ROOF PRIMER ROOFING** with a brush or roller, using 0.2 l/m<sup>2</sup>. Surfaces other than bitumen require less primer; concrete requires more.
- Allow the bonding varnish to dry for at least 3 hours.
- Finish with bitumen roofing membranes and/or coatings.



## Would you like more information?

We are ready to answer all your questions.

Feel free to contact us:

Belgium: 03 248 30 00 or [info@aquaplan.com](mailto:info@aquaplan.com)

The Netherlands: 0162 42 29 00 or [verkoop-dhz@martensgroep.eu](mailto:verkoop-dhz@martensgroep.eu)

Website: [www.aquaplan.com](http://www.aquaplan.com)

